


## Sea-Dog Light Tip Toggle Switches #420121 - 420129 Wiring Instructions




### **420121(-1)**

On / Off  
 Single Pole / Single Throw  
 Clear Off / Red On

### **420122(-1)**

Mom. On / Off  
 Single Pole / Single Throw  
 Clear Off / Red On



### **420123(-1)**


On / Off / On  
 Single Pole / Double Throw  
 Clear Off / Red On

### **420124(-1)**

Mom. On / Off / Mom. On  
 Single Pole / Double Throw  
 Clear Off / Red On

### **420125(-1)**

Mom. On / Off / On  
 Single Pole / Double Throw  
 Clear Off / Red On



### **420128(-1)**

On / Off / On  
 Double Pole / Double Throw  
 Clear Off / Red On

### **420129(-1)**

Mom. On / Off / Mom. On  
 Double Pole / Double Throw  
 Clear Off / Red On